




Spare part kits

Description

Position number included in kit

Seal kit	118, 122, 126, 225, 227, 233, 715, 751
Bearing shell kit	251, 252
Setting piston kit	131, 132, 134, 135, 151, 153
Bush Assy	450
Rotating bearing kit	237, 460, 470, 471
Cylinder Barrel Assy kit	411, 415, 416, 417, 441
Cover kit	120, 122, 123

Pos	Description	Qty	Remarks
111	Barrel Housing Left	1	Type L
111	Barrel Housing Right	1	Type R
117	Guide Pin	2	Included in pos 141
118	Hex Socket Plug R1/4 Assy	1	Seal kit
120	Cover	1	Cover kit
122	O-ring	1	Seal kit OR Cover kit
123	Hexagon Screw	4	Cover kit
126	Hex Socket Plug M14 Assy	2	Seal kit
131	Bar Assy	1	Setting piston kit
132	Compression Spring	1	Setting piston kit
134	Washer	1	Setting piston kit
135	Hexagon Socket Screw	1	Setting piston kit
141	Valveplate L	1	Including pos 117
141	Valveplate R	1	Including pos 117
151	Piston Assy	2	Setting piston kit
153	Compression Spring	2	Setting piston kit
211	Bearing Housing	1	Rep. 3796837
225	O-ring	1	Seal kit
227	Gasket	1	Seal kit
231	Seal Carrier	1	
233	Sealing ring	2	Seal kit
237	Retaining Ring Jk62	2	Rotating bearing kit
246	Hexagon Socket Screw	6	M10*40 10.9
251	Bearing Shell	2	Bearing shell kit
252	Sunk Head Screw	2	Bearing shell kit
311	Shaft	1	
411	Cylinder Barrel	1	Cylinder Barrel Assy
415	Ball	1	Cylinder Barrel Assy
416	Compression Spring	1	Cylinder Barrel Assy
417	Plate	1	Cylinder Barrel Assy
420	Swashplate Assy type R	1	Size 045
420	Swashplate Assy type L	1	Size 045
420	Swashplate Assy type R	1	Size 060
420	Swashplate Assy type L	1	Size 060
420	Swashplate Assy type R	1	Size 075
420	Swashplate Assy type L	1	Size 075
441	Piston Assy	9	Cylinder Barrel Assy
450	Bush Assy	5	Bush Assy kit
460	Plain Bearing	1	Rotating bearing kit
470	Tap Rol Bearing	1	Rotating bearing kit
471	Inner Ring	1	Rotating bearing kit
601	Hex Skt Screw M8*60 8.8	4	Incl. in pos 700
700	Control Ls Assy	1	Incl. in pos 601 & 715
715	O-ring	4	Seal kit + Incl. in pos 700
751	Sealing nut	1	Seal kit + Incl. in pos 700