



xxx- Pump Flow cc/rev

41- 400 bar

#- Direction of Rotation- Part codes ending in (C) will refer to Clockwise rotation, (A) will refer to Anti-clockwise rotation.

For installation and oil recommendations please refer to the General Instructions document. www.technical.edbro.com