

TXV 130 and 150 indexable - Characteristics



# TXV indexable series

displacements 130 and 150 cc/rev

# pumps with Load Sensing control

variable displacement piston pumps

## ADVANTAGES OF THE indexable SERIES

- ▶ Able to rotate in either direction, simply by changing position of the indexing screw!
- > Stock optimisation: only one reference regardless of direction of rotation!
- Pump supplied with its inlet fitting.



Minimum size envelope High rotating speeds High output pressure

Pump reference		Direction of rotation	Max. displace- ment <sup>(1)</sup>	Maximum operating pressure	Maximum peak pres- sure (intermittent: 5%)	Torque at 300 bar <sup>(2)</sup>	Max. speed at full dis- placement <sup>(3)</sup>	Max. speed in stand-by		Overhang torque <sup>(4)</sup>
			cu.in (cc)	psi (bar)	(bar)	lbf ft (N.m)	(rpm)	(rpm)	lbs (kg)	lbf ft (N.m)
TXV 130 indexable	P001474	CW/CCW	7.93 (130)	365	5500 (380)	538.42 (730)	1750	3000	59.97 (29.3)	25.81 (42)
TXV 150 indexable	P001475	CW/CCW	9.15 (150)	310	4786 (330)	619.60 (840)	1750	3000	59.97 (29.3)	25.81 (42)

<sup>(1)</sup> TXV pumps can be set for smaller maximum displacements (see page 41).

<sup>(2)</sup> For a mechanical efficiency at 85%.


<sup>(3)</sup> Higher speed - at full displacement - possible depending on flow required : please contact us.


<sup>(4)</sup> Value of the overhang torque of the only pump.

# PB TXV 130 & 150 indexable



## Dimensions - TXV 130 and 150 indexable





#### ► How to change direction of rotation

### Figure 1

- Remove the 4 screws 1.
- Take off the 2 half-flanges 2 and the inlet fitting 3.

  Take care not to lose the seal from the inlet fitting.
- Remove the plug 4 and the setting screw 5.
- <u>Do not</u> turn the pump shaft when the setting screw is not in place.

### Figure 2

- Put the setting screw 6.
- in the place where the plug 4 was, and put the plug 4 where the setting screw 5 was.
- Check the inlet fitting 6 seal is present, and in good condition.
- Put the inlet fitting 3, half-flanges 2 and screws 1 onto the side where the plug 4 is.

PLEASE NOTE: Unless otherwise specified, TXV pumps are supplied from factory set for clockwise (CW) rotation.